



# Setup Guide T7400A




## Items Included




1




2




3




4




5




6



7



8



# T7400A BASIC OPERATIONS GUIDE

## PAGING

### Guest Pagers: Return guest pagers to charging unit after paging

#### Non-Alphanumeric (Adverteaser, Pizza, Lobster, Coaster Call pagers)

1. Main screen displays – Guest #: - - - -
2. Enter number assigned to guest at handout
3. Press **ENTER** to send page

#### Alphanumeric (Alpha Coaster pager)

1. Main screen displays – Guest #: Guest #: - - - -
2. Enter number assigned to guest at handout
3. Enter message code (000-099) (see Canned Messages Table)
4. Press **ENTER** to send page

### Staff Pagers

#### Non-Alphanumeric (Star Pager)

1. On keypad press **STAFF** (Display – Pager #: - - - -)
2. Enter staff pager number to be paged
3. Press **ENTER** to send page

### Alphanumeric (Alphanumeric, Rechargeable alphanumeric pagers)

1. On keypad press **STAFF** (Display – Pager #: - - - -)
2. Enter staff pager number to be paged
3. Enter message code (000-099) (see Canned Messages Table)
4. Choose **F1** (V1), **F2** (V2) or **F3** (V3) for 1, 2 or 3 vibrations
5. Press **ENTER** to send page

### Assign Manager Pagers:

1. Press **SETUP**
2. Press **F1** (MORE) twice
3. Enter Authorization Code: 5-6-7-8-9
4. Press **3** (Prgm Mgr1/Mgr2)
5. Enter pager # assigned to MGR1 and press **ENTER**
6. Press **F1** (OK)
7. Enter pager # assigned to MGR2 and press **ENTER**

### Page a Manager Pager:

1. On keypad press **MGR1** or **MGR2**
2. Press **F1** (YES) to continue or **F4** (NO) to cancel
3. Enter message number code (000-099) (see Canned Messages Table)
4. Choose **F1** (V1), **F2** (V2), **F3** (V3) or **F4** (Exit) for 1, 2 or 3 vibrations

### All Call Page: Page all non-alphanumeric Guest and Staff Pagers simultaneously

#### At Main Screen Display:

1. Enter 000 then press **ENTER**
2. At Page All? Press **F1** (YES) or **F4** (NO)

### All Staff Page: Page all alphanumeric staff pagers simultaneously

1. Press **STAFF**
2. Press 9-1-1 then **ENTER**
3. Enter message number code (000-099)
4. Choose **F1** (V1), **F2** (V2) or **F3** (V3) for 1, 2 or 3 vibrations

## PRE-CANNED MESSAGES

### Using Message Codes

When prompted for a message:

1. Enter message number code (and a numeric extension – optional)
2. Press **ENTER**

#### Example: Send a message to call extension 123

From Canned Message Table below, choose – 006 (Call Ext)  
Enter code 0-0-6-1-2-3 (Displays: CALL EXT 123)

### Create Additional Alpha Messages: For Alpha pagers only

1. Press **SETUP**
2. Press **F1** (MORE) twice
3. Enter Authorization code: 5-6-7-8-9
4. Press **F1** (MORE) 5 times
5. Press **2** (Canned Msgs.)
6. Press **F1** (EDIT)
7. Press **F2** (NEW) to write a new message (Press **F1** (EDIT) to edit displayed message)
8. Enter message using alphanumeric typing (i.e. for letter 'E' press #2 twice)
9. Press **ENTER** to save then **F4** (EXIT) when finished

## MISC. FUNCTIONS

### Anti-Theft Mode: (Signal pagers that are out of range)

1. Press **SETUP**
2. Press **3** (THEFT ON/OFF)
3. Press **F1** (ON) to activate anti-theft mode or (press F2 to turn OFF)
4. Main screen display will show "T" on upper left corner when turned on

### Run Locate: (Locate all guest pagers)

1. Press **SETUP**
2. Press **F1** (MORE) twice
3. Enter Authorization Code: 5-6-7-8-9
4. Press **F1** (MORE) once
5. Press **3** (Run Locate)
6. Press **F2** (MODE)
7. Select **1** (BEEP) or **2** (Flashing)
8. Press **F1** (GO) to start locating

### Range Testing: Find the range of your paging system

1. Press **SETUP**
2. Press **F1** (MORE) twice
3. Enter Authorization Code: 5-6-7-8-9
4. Press **F1** (MORE) 4 times
5. Press **F2** (Run Range Test)
6. Test distance by walking around premise – pager will vibrate every 5-10 seconds to indicate that it is within range
7. Press **F4** (EXIT) to stop range test

### Set Time/Date:

1. Press **SETUP**
2. Press **F1** (MORE)
3. Press **1** (Set Time/Date)
4. Press **F1** (SET) to set time/date
5. Enter Time - - : - - and press **ENTER**
6. Press **F1** (AM) or **F4** (PM)
7. Enter Date (MM/DD/YY) and press **ENTER**
8. (OPTIONAL) Press **1** (Send to Pager) to send date and time to Alphanumeric Manager pagers.

For advanced features, go to [pager.net](http://pager.net) for a complete user manual. For technical support call Long Range Systems at 800-437-4996.

## Canned Message Code

### Code Message

<b>000</b> Phone Call	<b>020</b> Starter	<b>040</b> Door	<b>060</b> Car
<b>001</b> Sales Call	<b>021</b> Service drive	<b>041</b> Survey	<b>061</b> Bus
<b>002</b> Manager	<b>022</b> Showroom	<b>042</b> T-nnn Q-mm	<b>062</b> Bay
<b>003</b> Customer	<b>023</b> Parked Call	<b>043</b> Break	<b>063</b> Low battery
<b>004</b> Room	<b>024</b> Voice Mail	<b>044</b> Fire	<b>064</b> Error
<b>005</b> Visitor	<b>025</b> Dressing room	<b>045</b> Unit	<b>065</b> Exit
<b>006</b> call Ext	<b>026</b> Price check	<b>046</b> Window	<b>066</b> Fax
<b>007</b> MTG Room	<b>027</b> Department	<b>047</b> Nurse	<b>067</b> host
<b>008</b> Lane	<b>028</b> Cashier	<b>048</b> Register	<b>068</b> Space
<b>009</b> Aisle	<b>029</b> Office	<b>049</b> Owner	<b>069</b> Location
<b>010</b> Void	<b>030</b> Table	<b>050</b> Check	<b>070</b> Nursery
<b>011</b> Stamps	<b>031</b> Winner	<b>051</b> Drink	<b>071</b> Teller
<b>012</b> Change	<b>032</b> Pickup	<b>052</b> Food	<b>072</b> Officer
<b>013</b> Station	<b>033</b> Dock	<b>053</b> Service	<b>073</b> Buffet
<b>014</b> Machine	<b>034</b> You have mail	<b>054</b> Seat	<b>074</b> Diaper change
<b>015</b> Operator	<b>035</b> Table ready	<b>055</b> Booth	<b>075</b> Child crying
<b>016</b> Emergency	<b>036</b> No special	<b>056</b> Lobby	<b>076</b> To nursery
<b>017</b> XX Minutes	<b>037</b> Hole	<b>057</b> Help	
<b>018</b> Tee	<b>038</b> Kitchen	<b>058</b> Restroom	
<b>019</b> Pro Shop	<b>039</b> Bar	<b>059</b> Valet	



800.437.4996  
[www.pager.net](http://www.pager.net)